



Spacer Lengths

6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

			Lower 1"	Lower 2"
Honda	88-07	VT600C Shadow/Deluxe/VLX	3.00"	2.00"
Honda	94-03	VF750C Magna/Deluxe	4.00"	3.00"
Honda	98-03	VT750 Shadow ACE	4.00"	3.00"
Honda	01-09	VT750 Shadow Spirit (chain-drive)	3.00"	2.00"
Honda	85-07	1100 Shadow/Ace/Spirit/Sabre	4.00"	3.00"
Honda	98-02	VT1100 Aero*	*4.50"	3.50"
Honda	1997	X-4 1300(non-USA model)	9.00"	8.00"
Honda	04-09	VTX1300C	2.50"	1.50"
Honda	03-09	VTX1300R/S Retro	3.00"	2.00"
Honda	08-09	VTX1300T	2.75"	1.75"
Kawasaki	85-87	ZL900/1000 Eliminator	1.00"	0"
Kawasaki	95-06	VN800 Vulcan/Classic/Drifter	3.00"	2.00"
Kawasaki	96-08	VN1500 Vulcan Classic	3.00"	2.00"
Kawasaki	87-99	VN1500 Vulcan/L	1.00"	0"
Kawasaki	87-90	VN1500 Vulcan SE	*5.25"	*4.25"
Kawasaki	98-01	VN1500 Vulcan Nomad	3.25"	2.25"
Kawasaki	99-05	VN1500 Vulcan Drifter	2.50"	1.50"
Kawasaki	03-08	VN1600 Vulcan Classic	4.65"	3.65"
Suzuki	85-87	VS700 Intruder	1.75"	0.75"
Suzuki	88-09	VS750/800 Intruder/Blvd.S50	1.75"	0.75"
Suzuki	87-09	VS1400 Intruder/Blvd.S83	3.00"	2.00"
Triumph	02-14	Bonneville America/Speedmaster	*6.12"	*5.12"
Triumph	01-14	Bonneville / T100	2.00"	1.00"
Triumph	08-14	Rocket III - Touring	8.50"	7.50"
Yamaha	1996	XVS400 Drag Star	.75"	0"
Yamaha	98-10	V-Star 650/Classic/Silv.	2.75"	1.75"
Yamaha	84-97	700/750 Virago	5.00"	4.00"
Yamaha	84-99	1000/1100 Virago	5.00"	4.00"
Yamaha	99-09	V-Star 1100/Custom/Classic/Silv.	1.00"	0"
Yamaha	85-92	V-Max 1200	4.25"	3.25"
Yamaha	93-07	V-Max 1200	8.37"	7.37"
Yamaha	99-12	Road Star (not Warrior)	5.50"	4.50"
Yamaha	06-14	Roadliner/Stratoliner	8.20"	7.20"

*Cut stock spacers to indicated length for this model.

www.progressivesuspension.com

Copyright © 2016 by Progressive Suspension, All Rights Reserved.



Spacer Lengths

6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

			Lower 1"	Lower 2"
Honda	88-07	VT600C Shadow/Deluxe/VLX	3.00"	2.00"
Honda	94-03	VF750C Magna/Deluxe	4.00"	3.00"
Honda	98-03	VT750 Shadow ACE	4.00"	3.00"
Honda	01-09	VT750 Shadow Spirit (chain-drive)	3.00"	2.00"
Honda	85-07	1100 Shadow/Ace/Spirit/Sabre	4.00"	3.00"
Honda	98-02	VT1100 Aero*	*4.50"	3.50"
Honda	1997	X-4 1300(non-USA model)	9.00"	8.00"
Honda	04-09	VTX1300C	2.50"	1.50"
Honda	03-09	VTX1300R/S Retro	3.00"	2.00"
Honda	08-09	VTX1300T	2.75"	1.75"
Kawasaki	85-87	ZL900/1000 Eliminator	1.00"	0"
Kawasaki	95-06	VN800 Vulcan/Classic/Drifter	3.00"	2.00"
Kawasaki	96-08	VN1500 Vulcan Classic	3.00"	2.00"
Kawasaki	87-99	VN1500 Vulcan/L	1.00"	0"
Kawasaki	87-90	VN1500 Vulcan SE	*5.25"	*4.25"
Kawasaki	98-01	VN1500 Vulcan Nomad	3.25"	2.25"
Kawasaki	99-05	VN1500 Vulcan Drifter	2.50"	1.50"
Kawasaki	03-08	VN1600 Vulcan Classic	4.65"	3.65"
Suzuki	85-87	VS700 Intruder	1.75"	0.75"
Suzuki	88-09	VS750/800 Intruder/Blvd.S50	1.75"	0.75"
Suzuki	87-09	VS1400 Intruder/Blvd.S83	3.00"	2.00"
Triumph	02-14	Bonneville America/Speedmaster	*6.12"	*5.12"
Triumph	01-14	Bonneville / T100	2.00"	1.00"
Triumph	08-14	Rocket III - Touring	8.50"	7.50"
Yamaha	1996	XVS400 Drag Star	.75"	0"
Yamaha	98-10	V-Star 650/Classic/Silv.	2.75"	1.75"
Yamaha	84-97	700/750 Virago	5.00"	4.00"
Yamaha	84-99	1000/1100 Virago	5.00"	4.00"
Yamaha	99-09	V-Star 1100/Custom/Classic/Silv.	1.00"	0"
Yamaha	85-92	V-Max 1200	4.25"	3.25"
Yamaha	93-07	V-Max 1200	8.37"	7.37"
Yamaha	99-12	Road Star (not Warrior)	5.50"	4.50"
Yamaha	06-14	Roadliner/Stratoliner	8.20"	7.20"

*Cut stock spacers to indicated length for this model.

www.progressivesuspension.com

Copyright © 2016 by Progressive Suspension, All Rights Reserved.