



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha 950 V-Star & 1300 Stryker 465 Series Single Shock Supplement

Please read these instructions completely before starting!

Mount the shock, referencing your authorized shop manual, noting the following important details;

Make sure the shock is mounted with the rebound adjustment toward the rear and facing the left side of the motorcycle and the nitrogen pressure valve is facing rearward. Use the supplied 12mm flange bolt and locknut for the clevis end when installing this shock. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: *The installed spring length must never be set shorter than 151mm (5.95") for 465-1176 and 141mm (5.56") for 465-1177 or shock damage may occur.*

<http://www.progressivesuspension.com>



6911 Marlin Circle, La Palma, CA 90623
(714) 523-8700, Fax (714) 523-3220

Yamaha 950 V-Star & 1300 Stryker 465 Series Single Shock Supplement

Please read these instructions completely before starting!

Mount the shock, referencing your authorized shop manual, noting the following important details;

Make sure the shock is mounted with the rebound adjustment toward the rear and facing the left side of the motorcycle and the nitrogen pressure valve is facing rearward. Use the supplied 12mm flange bolt and locknut for the clevis end when installing this shock. Tighten the shock bolts to the proper torque specifications (refer to your manual).

Caution: *The installed spring length must never be set shorter than 151mm (5.95") for 465-1176 and 141mm (5.56") for 465-1177 or shock damage may occur.*

<http://www.progressivesuspension.com>