



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Yamaha Road Star 465 Series Single Shock Supplement

Please read these instructions completely  
before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing up. Tighten the shock bolts to the proper torque specifications (refer to your manual)

Caution: The installed spring length must never be set shorter than 132mm (5.20") for 465-1139 and 121mm (4.74") for 465-1140 or shock damage may occur.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Yamaha Road Star 465 Series Single Shock Supplement

Please read these instructions completely  
before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing up. Tighten the shock bolts to the proper torque specifications (refer to your manual)

Caution: The installed spring length must never be set shorter than 132mm (5.20") for 465-1139 and 121mm (4.74") for 465-1140 or shock damage may occur.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Yamaha Road Star 465 Series Single Shock Supplement

Please read these instructions completely  
before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing up. Tighten the shock bolts to the proper torque specifications (refer to your manual)

Caution: The installed spring length must never be set shorter than 132mm (5.20") for 465-1139 and 121mm (4.74") for 465-1140 or shock damage may occur.



6911 Marlin Circle, La Palma, CA 90623  
(714) 523-8700, Fax (714) 523-3220

## Yamaha Road Star 465 Series Single Shock Supplement

Please read these instructions completely  
before starting!

1. Mount the shock, referencing your authorized shop manual, noting the following important details: Make sure the shock is mounted with the rebound adjustment at the bottom and facing the left side of the motorcycle and the nitrogen pressure valve is facing up. Tighten the shock bolts to the proper torque specifications (refer to your manual)

Caution: The installed spring length must never be set shorter than 132mm (5.20") for 465-1139 and 121mm (4.74") for 465-1140 or shock damage may occur.