Inst # 3098-101 Rev. C

## PROGRESSIVE®

6911 Marlin Circle, La Palma, CA 90623 (714) 523-8700, Fax (714) 523-3220

## Softail Supplement—Adjustable Eye's

Your new adjustable ride height shocks are capable of: Stock to 2" lower ride height.

The shocks come pre-assembled set at 1.0" lower than stock height.


To adjust the ride height simply loosen the lock nut on the eye, and turn the hex on the shaft to the desired height. The more threads that are exposed, the lower the ride height. You can make the adjustment on the bike, just adjust both shocks together, turning each one at the same time.

It is important that the locknut on the pre-load adjusting plate is securely tightened.

When turning the shaft, the preload adjuster plate or the entire spring housing may turn along with the shaft, this is ok, it is not changing your preload setting.

When you reach the desired height, tighten the locknut on the eye down securely(14ft./lb.) on both shocks.

The maximum setting is 9/16" of exposed threads, measured from the locknut to the end of the threads. This equals a 2" lower ride height. 5/16" eye adjustment equals approx. 1" ride height change. Warning: Do not go further than this—damage or injury may result.




http://www.progressivesuspension.com Copyright ' 1999 by Progressive Suspension, All Rights Reserved.



When turning the shaft, the preload adjuster plate or the entire spring housing may turn along with the shaft, this is ok, it is not changing your preload setting.

height. 5/16" eye adjustment equals approx. 1" ride height change. Warning: Do not go further than this—damage or injury



http://www.progressivesuspension.com Copyright ' 1999 by Progressive Suspension, All Rights Reserved.