

11129 G Avenue
(760) 948-4012



Hesperia, CA 92345
Fax (760) 948-4307

Damper Rod Installation Instructions for Harley Davidson's w/39mm Forks

Fits models with 39mm forks: 87-up FXRS-SP
88-up FX
88-94 XL


Note: Please read all instructions thoroughly before starting installation!

1. Securely block the motorcycle so that the front wheel is slightly off the ground.
2. Per the authorized service manual (pertaining to your make, model and year) remove the forks and disassemble.
3. Carefully remove stock piston ring and the stock top-out spring from the stock damper rods, carefully reinstall them on the new Progressive Suspension damper rods (see figure).
4. Reassemble the forks with the Progressive Suspension damper rods.

Note: Forks should be fully compressed before tightening the damper rod bolts for proper alignment.

5. Fill the forks with the correct amount of oil from your service manual. We recommend a high quality 15wt fork oil for proper fork performance.
6. Install the forks per the service manual pertaining to your make, model and year.
7. For total suspension control, we recommend a pair of our Progressive Suspension fork springs and rear shocks for a balanced suspension.

Note: These damper rods are designed to increase your rebound damping while not affecting the compression damping. Giving you a very comfortable and controllable ride.



Inst # 3079-002

<http://www.progressivesuspension.com>

11/11/98

11129 G Avenue
(760) 948-4012



Hesperia, CA 92345
Fax (760) 948-4307

Damper Rod Installation Instructions for Harley Davidson's w/39mm Forks

Fits models with 39mm forks: 87-up FXRS-SP
88-up FX
88-94 XL


Note: Please read all instructions thoroughly before starting installation!

1. Securely block the motorcycle so that the front wheel is slightly off the ground.
2. Per the authorized service manual (pertaining to your make, model and year) remove the forks and disassemble.
3. Carefully remove stock piston ring and the stock top-out spring from the stock damper rods, carefully reinstall them on the new Progressive Suspension damper rods (see figure).
4. Reassemble the forks with the Progressive Suspension damper rods.

Note: Forks should be fully compressed before tightening the damper rod bolts for proper alignment.

5. Fill the forks with the correct amount of oil from your service manual. We recommend a high quality 15wt fork oil for proper fork performance.
6. Install the forks per the service manual pertaining to your make, model and year.
7. For total suspension control, we recommend a pair of our Progressive Suspension fork springs and rear shocks for a balanced suspension.

Note: These damper rods are designed to increase your rebound damping while not affecting the compression damping. Giving you a very comfortable and controllable ride.



Inst # 3079-002

<http://www.progressivesuspension.com>

11/11/98